


efbe-Schott[®]

Instructions for Dual Rotary Sweeper

1. Remove sweeper and handle tube assembly from their bags, ensure bags are safely stored as they can be hazardous to small children.
2. At the bottom of the handle tube assembly is a U-clip; this fastens into the male tab of the sweeper body, push firmly and directly down onto this male tab, you will hear and feel a click as the 2 parts engage.
3. Adjust the handle length by unlocking each section (grasp and turn anti-clockwise), adjust then lock (grasp and turn clockwise).
4. Pull the handle to open the dust compartment – do this over a bin or other dust collection receptacle.
5. You can disassemble the whole of the sweeper if it needs a thorough clean, see diagram below:



Issue 1
2010-09-28